



INSTRUCTIONS DE MONTAGE
 MONTAGEANLEITUNG
 INSTRUCTIONS FOR ASSEMBLY
 INSTRUCCIONES DE MONTAJE

WIN-Slide 2


NM_WINSL_065



Déplacement manuel
 Antrieb: manuell
 Manual move



Déplacement manuel
 Antrieb: manuell
 Manual move








Déplacement motorisé
 Antrieb: motorisiert
 Motorized move



Epaisseur des panneaux
 Ladendicke
 Shutter thickness
 Espesor de las hojas




40 - 80 mm
 -
80 Kg


Epaisseur des panneaux
 Ladendicke
 Shutter thickness
 Espesor de las hojas

40 - 60 mm
 -
80 Kg








			
C	90 min	90 min	
D	B + 150 min	B + 150 min	B + 380 min
W	H - 90	H - 98	
T	40 - 80	40 - 60	




1








2.a




2.b





R	(B x 2) + 220	(B x 2) + 240




2.c









2.d



3



		
a	11286XA2 ou/or/oder 11287XA2	11286XA2-SYN
b	11286XA2 ou/or/oder 11287XA2	11286XA2
c	11281XA4	11281LXA4



11286XA2


11287XA2

11286XA2-SYN



11281XA4

11281LXA4




3.b



3.c





	11281XA4	11281LXA2
E	22	42




8


5.a




5.b




6.a




6.b




7.a





7.b




7.c





7.d






8.a



8.b



		
G	= R	= R + 215



9.a

